



## EXPLANATION OF NUMBERING SYSTEMS & SYMBOLS

### FIRST TWO/FOUR CHARACTER DENOTES STYLE/FUNCTION OF HINGE:

2B	=	2 Knuckle Ball Bearing
2H	=	2 Knuckle Ball Bearing Heavy Weight
2P	=	2 Knuckle Plain Bearing
4B	=	4 Ball Bearing Heavy Weight
4C	=	Concealed Bearing Heavy Weight
4F	=	5 Knuckle Concealed Heavy Weight
PB	=	Plain Bearing
BB	=	Ball Bearing
CP	=	Concealed Plain Bearing
CB	=	Concealed Bearing
CH	=	Continuous Heavy Weight
FB	=	5 Knuckle Concealed Bearing
IT	=	3/16" Slip-In Insert
IF	=	5/16" Slip-In Insert
PF	=	Concealed Bearing Heavy Weight Prison Hinge
RB	=	Raised Barrel
RS	=	Residential Spring Hinge
RP	=	Residential Plain Bearing
SP	=	Spring Hinge
SC4B	=	Swing Clear Heavy Weight
SCPB	=	Swing Clear Plain Bearing
SCBB	=	Swing Clear Ball Bearing
WT4B	=	Wide Throw Heavy Weight
WTPB	=	Wide Throw Plain Bearing
WTBB	=	Wide Throw Ball Bearing
WB	=	Welding Butt

### THIRD/FIFTH CHARACTER DENOTES BASE MATERIAL USED:

8	=	Wrought Steel
5	=	Stainless Steel
3	=	Aluminum
2	=	Wrought Brass

### FOURTH/SIXTH CHARACTER DENOTES TYPE OF HINGE:

1	=	Full Mortise
2	=	Half Mortise
3	=	Full Surface
4	=	Half Surface

Example 1 = PB81

PB = Plain Bearing  
8 = Steel  
1 = Full Mortise

Example 3 = SP51

SP = Spring Hinge  
5 = Stainless Steel  
1 = Full Mortise

Example 2 = 4B24

4B = Four Bearing Heavy Weight  
2 = Brass  
4 = Half Surface

Example 4 = SC4B83

SC4B = Swing Clear Heavy Weight  
8 = Steel  
3 = Full Surface